

2019 **SPLASH** DualSync Fishing Bow TECHNICAL BULLETIN 112018R4

The **SPLASH** DualSync **FB** has an adjustable peak weight range. The **50 lb. PEAK WEIGHT** is adjustable 35 – 50 lbs. To adjust peak weight first tighten your limb bolts down to be sure the limbs are even. Count the turns when you tighten the limbs down so you know where you started. A maximum of 7 **Counter Clock Wise** turns from the tightened position is recommended, more than 7 turns and the bow will not perform as advertised. Too many turns and the bow could become un-safe. An inspection hole shows the amount of threads remaining at the end of each limb bolt. Do not shoot the bow unless at least one thread is visible.

There are no tools or press bow press required to change draw lengths. With all **SPLASH** bows, there is no need to **change anything to shoot at different draw lengths. The maximum draw length can be set using the perimeter limb stop (23 ½" - 29 ½") to prevent over drawing an arrow.**

SPLASH FB cams are designed to accommodate special Bow Fishing **requirements**. The use of these cams makes the bow fishing experience less fatiguing and more enjoyable. By obtaining peak weight early in the draw cycle and a low holding weight (50% let-off) beginning at 23 ½", all the way to 29 ½", you have a bow that can be released anywhere during the draw cycle with powerful results. This also makes the bow very versatile and not sensitive to different draw lengths. The **FB** Cams are standard on all 2019 Splash bows.

The **SPLASH** Fish Bow includes a high gloss blue riser with matching strings and cables. Included in the Splash FB package are SS axles, SS Ball Bearings & all SS fasteners, that includes all screws & limb bolts. Also included are soft rubber finger protectors installed on the bowstring. **Available from Darton** is a special **SPLASH Fishing Package** that includes all the highest quality accessories needed to go bow fishing.

Darton's Parallel Limb Design coupled with its DualSync Cam System provides satisfying smoothness with each shot. This is enhanced by the use of **DARTON's low mount Bowstring Suppression Unit. The bumper should be adjusted to just touch the bowstring.** If there is a gap between the rod end and the inside of the bumper, your bowstring may be deflected and slide off the bumper. The **BNSS** is adjusted by loosening its setscrew and then moving the rod in or out accordingly to position the bumper relative to the bowstring. Apply bowstring wax to the bowstring in the area that aligns with the suppressor bumper for best results.

If you need to remove your cables or cable guard slide be sure to replace them in their original positions or it will affect the way the power cables track in their respective grooves.

DARTON includes their patented **Tuning Mark System** on all **DualSync** bows to assist the individual shooter/tuner in getting optimum performance. By lining up the power cables between the tuning lines on the cam, you will get the advertised draw lengths and performance. The cable lengths are adjusted by first putting the bow in a press to remove tension from the cables. The cables are then adjusted by twisting to make them shorter and untwisting to make them longer. If the cables are not lined, up or in the same relative position on each module, you will lose some draw length and stored energy. The shoot-ability will remain the same. Be sure the axle-to-axle measurement is checked after the bow is tuned. The correct measurement will assure good performance.

w/100 pounds tension				
Draw Length	Brace Height	A-A	Bowstring	Power Cables
23 ½"	7"	28 ½"	52 5/8"	33 1/8"

Bowstrings and Power Cable measurements are with twist. Add or subtract twist in Power Cables to get correct tune. Axle – Axle tolerance is +/- 1/16".

For additional warranty or tuning information visit our web site www.dartonarchery.com or call Darton Service at 989-728-9511. To order parts, draw length modules or Darton Apparel call Darton Service at 989-728-4231.

Before pressing bow, back limbs out 4 turns from MAX setting. Darton's warranty does not cover damage to any bow caused by improper use of a bow press.